



***baja designs***<sup>®</sup>  
THE SCIENTISTS OF LIGHTING

**Super73, Model R,S,Z S1 Headlight Replacement Kit  
(44-8151, 44-8152)**



2950 Norman Strasse San Marcos, CA 92069 Phone 760-560-2252 X3 • Fax 760-560-0383 info@bajadesigns.com •

[www.bajadesigns.com](http://www.bajadesigns.com)

# LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

**Exclusions:** Installation errors, abuse, misuse, or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties. Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace it with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise. Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

**Indemnification: Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies. Buyer is responsible for ensuring that it uses the products (and its vehicle) in accordance with all applicable laws, regulations, guidelines, and standards of care. Buyer acknowledges that some products may only be used when off-roading, and**

**Buyer will comply with all vehicle and road safety guidelines. Buyer is solely responsible for (and will indemnify and hold Bestop harmless for) any claims, losses, damages, fines, fees, costs, or other amounts arising out of Buyer's non-compliance with these provisions.**

**Required Tool(s)**

- 3mm Hex Key
- 4mm Hex Key
- 10mm Wrench

**Required Parts**

 <p><b>(38-8017) (Qty: 1)</b> S1, Super73, For Kits Light Upside Down W/C Amber <b>Only for 44-8151</b></p>	 <p><b>(38-8016) (Qty: 1)</b> S1, Super73, For Kits Light Upside Down W/C Clear <b>Only for 44-8152</b></p>	 <p><b>(65-0213) (Qty: 1)</b> Parts Bag, S1 Single, For Kits</p>	 <p><b>(4-9407) (Qty: 1)</b> Bracket, S1, Super73, Headlight</p>
 <p><b>(20-1610) (Qty: 4)</b> Hardware, Zip tie 4"</p>			

To begin, make sure the vehicle is in park, on level ground and the parking brake is engaged.

### Step 1: Remove Headlight Fairing

Remove the four M5 screws using a 3mm Hex Key (Circled in red). Remove the Fairing and place it in a safe place where it will not be damaged.



### Step 2: Remove Stock Headlight

With the plastic fairing removed, follow the power cable from the back of the light to the light connector and unplug it.

Once unplugged, remove the stock headlight by unscrewing the hex screw and nut using a 4mm hex key and a 10mm wrench on the back of the light.



### Step 3: Remove Stock Headlight Mounting Bracket

Remove the two screws that secure the mounting bracket to the triple clamp below the handlebars using a 4mm Hex Key. Remove the bracket.





**Step 4: Install the Baja Designs S1 Mounting Bracket**

Position the new mounting bracket in place and reinstall the two screws using a 4mm Hex Key that were removed in the previous step.



**Step 5: Install the S1 light to the mounting bracket**

Using the provided hardware in the hardware bag, install only the two M5 button head screws through the bracket and into the light using the 3mm Hex Key. Plug in the light and aim it so that the beam pattern is horizontal. With the light aimed properly, fully tighten down the mounting screws. Make sure the light is mounted with the “Baja Designs” text on the bottom of the bezel.





### Step 6: Reinstall the Fairing

Reinstall the fairing by reinstalling the four M5 screws using a 3mm Hex Key.

Ensure the handlebars maintain full range of motion without pinching or straining the cable.



**Tie all wires away from sharp, hot, and/or rotating components.**

**Re-torque all the fasteners after 100 miles.**

**Your install is now complete! Thank you for choosing Baja Designs.**